THESE INSTRUCTIONS SHOULD NOT BE FAXED OR REPRODUCED ON A DIGITAL COPIER. AMERICAN WOODMARK CORPORATION PROVIDES THESE INSTRUCTIONS ON AN "AS IS" BASIS AND DISCLAIMS ANY AND ALL LIABILITY FOR ANY INACCURACIES, OMISSIONS OR TYPOGRAPHICAL ERRORS CAUSED BY ANY THIRD PARTY'S EQUIPMENT. When you use these instructions, you are consenting to be bound by the provisions in this paragraph. These instructions provide an illustrative method for installing American Woodmark Corporation ("AWC") cabinets and/or accessories. AWC's instructions are not intended to address every possible contingency that might be encountered during installation or to endorse the use of any particular tools. AWC HEREBY EXPRESSLY DISCLAIMS ALL LIABILITY FOR ANY CLAIMS FOR INJURY OR DEATH RELATED TO OR BASED UPON THE USE OF THESE INSTALLATION INSTRUCTIONS AND ANY INSTALLATION INSTRUCTIONS OTHERWISE PROVIDED BY AWC.

Installation Instructions

Read carefully before you begin installation

Optional Range Hood Mantel Corbel Attachment

For Mounting Optional Corbels To Range Hood Mantels.

This kit is used for mounting Optional Corbels to Range Hood Mantels.

Contents

- Range Hood Mantle
- Corbels (Purchased individually or shipped separately)
- (2) #8 x 1 ½" Flat Head Screws per Corbel (not included)

Tools Needed

- Safety Glasses
- Drill
- 1/8" Drill Bit
- Pencil
- Tape Measure
- Wood Clamps
- Phillip Screwdriver

Procedure

Position Corbel into desired location and secure with Wood Clamps.

From the inside of the Range Hood Mantle, mark and pre-drill two pilot holes for each corbel approximately 1 ¹/₂" deep with the 1/8" drill bit.

CAUTION: Be sure to locate the pilot holes so that you do not drill through the front of the corbel.

HINT: Wrapping a piece of tape around the drill bit 1 ½" from the end will give a visual stopping point for the correct depth to drill.

Attach the Corbel to the Range Hood Mantle using (2) $\#8 \times 1 \frac{1}{2}$ wood screws.

Repeat Steps 1 through 3 for opposite side.



