THESE INSTRUCTIONS SHOULD NOT BE FAXED OR REPRODUCED ON A DIGITAL COPIER. AMERICAN WOODMARK CORPORATION PROVIDES THESE INSTRUCTIONS ON AN "AS IS" BASIS AND DISCLAIMS ANY AND ALL LIABILITY FOR ANY INACCURACIES, OMISSIONS OR TYPOGRAPHICAL ERRORS CAUSED BY ANY THIRD PARTY'S EQUIPMENT.

Installation Instructions

Read carefully before you begin installation

Shelf Support Supports Wide Half-Depth Shelves

Fits

Base Cabinets

Contents

- (1) Base Shelf Support
- (4) #6 X 1/2" Truss Head Phillips Recess Screws

Tools Needed

- Tape Measure or Ruler
- Pencil
- Phillips Screw Driver
- Safety Glasses

Procedure



- Remove adjustable shelf from cabinet.
- 2 Using your tape measure or ruler, measure the width of shelf and mark a middle point along the back edge of the shelf.
- 3 Align the center of the Shelf Support with your pencil mark and attach to the shelf using two #6 X 1/2" truss head phillips recess screws.

4 Position shelf in cabinet (with the Shelf Support against the back) at the desired location with the side panel shelf clips.

5 Attach the Shelf Support to the back using two #6 X 1/2" truss head phillips recess screws (being careful not to strip the screws).





The shelf is now ready for use.

10-0523-01