

THESE INSTRUCTIONS SHOULD ONLY BE PRINTED USING ADOBE ACROBAT AND SHOULD NOT BE FAXED OR REPRODUCED ON A DIGITAL COPIER. AMERICAN WOODMARK CORPORATION PROVIDES THESE INSTRUCTIONS ON AN "AS IS" BASIS AND DISCLAIMS ANY AND ALL LIABILITY FOR ANY INACCURACIES, OMISSIONS OR TYPOGRAPHICAL ERRORS CAUSED BY THE USER'S EQUIPMENT OR BY ANY THIRD PARTY'S EQUIPMENT.

ESTAS INSTRUCCIONES SÓLO SE DEBEN IMPRIMIR USANDO ADOBE ACROBAT Y NO SE DEBEN ENVIAR POR FAX NI SE DEBEN REPRODUCIR EN UNA COPIADORA DIGITAL. AMERICAN WOODMARK CORPORATION PROPORCIONA ESTAS INSTRUCCIONES "TAL COMO ESTAN" Y RENUNCIA A CUALQUIER Y A TODA RESPONSABILIDAD POR CUALQUIER FALTA DE PRECISIÓN, OMISIÓN O ERROR TIPOGRÁFICO CAUSADO POR EL EQUIPO DEL USUARIO O POR EL EQUIPO DE TERCERAS PERSONAS.

APPLIQUE VALANCE INSTALLATION SHEET

NOTE:

1. WHEN ATTACHING AN APPLIQUE VALANCE INTO A KITCHEN WHERE MOLDING IS TO BE USED, BE SURE TO INSTALL THE VALANCE BELOW THE TOP EDGE OF THE ADJACENT WALL CABINET(S) IN ORDER TO LEAVE ENOUGH SPACE SO THAT THE MOLDING DOES NOT INTERFERE WITH THE APPLIQUE. DIFFERENT MOLDINGS WILL REQUIRE DIFFERENT SPACINGS. CLEATS MAY BE NEEDED TO BE USED TO ATTACH THE MOLDING TO THE VALANCE.

